SUNLITE

BURN HEADLIGHT USER MANUAL



INSTALLATION INSTRUCTIONS



1. Unfold the strap of the bracket and wrap it around the handlebar.



2. Install the thumb screw over the strap and tighten.



3. Insert the headlight onto the base and turn 90° to lock into place.



4. After installing, adjust the light as necessary so that it lights your path without blinding drivers and pedestrians.

Fully charge the light before first use

ON/OFF: Press and hold the power button for 0.5 seconds.

MODE: When the light is on, quick press the button to switch brightness levels. Double click the button to switch between steady and flashing modes.

PARTS INCLUDED









HEADLIGHT

HANDLEBAR MOUNT

GOPRO STYLE MOUNT

JSIYLE USBC

LUMENS & RUNTIME

BURN 400

MODE	HIGH	MED	LOW	ECO	FLASH 1	FLASH 2
LUMENS	400	300	250	100	100	250
TIME	2H10	3H10	4H30	11H	22H	9H

BURN 600

MODE	HIGH	MED	LOW	ECO	FLASH 1	FLASH 2
LUMENS	600	450	350	150	150	350
TIME	1H40	2H10	3H20	9H	19H	7H

BURN 800

MODE	HIGH	MED	LOW	ECO	FLASH 1	FLASH 2
LUMENS	800	630	480	200	200	480
TIME	1H30	2H	2H45	6H45	13H	5H30

CHARGING





Charging:Red

Fully charged: Green

- 1. Open the USB cover and insert the charging cable into the USB Type-C Port.
- 2. Connect the other end of the cable to a USB wall port or charging recepticle.
- 3. After charging, be sure to replace the waterproof cover.

PRECAUTIONS

- Never look directly into the light or shine it in other's eyes.
- Do not touch the metal head after use it will be hot.
- When charging use a 5V-1A power adapter.
- Battery must be charged every 3 months to avoid damage.
- After charging, be sure to unplug the cable.
- Do not store in vehicles or near heat sources.
- Please charge in temperatures between 40°F -90°F

SUNLITE



Please note: The light is locked during shipping. To lock/unlock, press the power button 5 times in quick succession.



Lock light when not in use, or while transporting off the bike to prevent heat damage from accidental activation.