

Miami Sun Trike Canopy

#93854

Assembly Instructions

1. With rear basket removed, position uprights onto rear unit supports as shown in **Fig. 1**. Note that shorter upright is positioned forward.



Fig. 1



Fig. 2

2. Lower basket onto uprights as shown in **Fig. 2**.

3. Position basket straps and install basket hardware as shown in **Fig. 3**. Tight securely.



Fig. 3



Fig. 4

4. Position 'J' bars and clamps as shown in **Fig. 4**. Assemble canopy top frame and position at desired height. Tighten all clamps securely.

5. Attach canvas and secure all straps. Note Miami Sun Logo is at the rear as shown in **Fig. 5**.



Fig. 5

Imported and distributed by:
J&B Importers, Inc.
Miami, FL