

edge wind fairing logo
Part No. 94632



Fig. 1



Fig. 2



Fig. 3

- 1). Loosely attach **lower bracket (A)** and **lower brace (B)** onto handle bar stem as shown in Fig. 1. Note: you may or may not need the silver shims provided with the bracket.
- 2). Loosely attach **upper bracket (C)** and **upper brace (D)** onto handle bar as shown in Fig. 2 & 3.
- 3). Assemble **rigid washer (G)** then **soft washer (H)** onto the **nylon screws (F)**.
- 4). Insert assembled screws from step 4 through the two lower holes in the fairing and put **rubber gasket (I)** over the two protruding screws.
- 5). Attach the fairing onto the lower brace and affix with nylon **wing nuts (J)** as shown in FIG. 1.
- 6). Repeat steps 4 and 5 with the upper holes and upper brace as shown in FIG. 2 & 3.
- 7). Align all your braces and brackets and tighten securely.

