

Foot Pump

Instruction Manual


PU004

Please read all instructions before installing and using your hand pump.

Please wear shoes while operating.

Warning ⚠

Please refer to the PSI rating for each pump model and your tire before using your pump.



Installation/Use

Using Your Foot Pump

1. Attach the pump hose to the tube valve and flip the thumb lock down.
2. Begin pumping by pressing down on the foot lever.
3. Monitor the pressure and make sure you do not over fill the tube with air. Do not exceed the recommended amount of PSI for your tire. Your tire's PSI rating should be stamped on the sidewall.

Your Pump's Gauge

1. The gauge's clear plastic cover has a red pressure guide needle that is adjustable. Before operating your foot pump, set this needle to the desired pressure by rotating the black plastic gauge cover. This will NOT automatically stop the air pressure entering the tire. It is for a quick reference of how much tire pressure you have pumped into the tire and to remind you when to stop pumping.

*It is strongly recommended to wear shoes while operating your foot pump. Failure to do so may cause serious injury to the user.