
Full Fender (Axle Mount)

Please read all instructions before installing and using your new fenders.

Please note: These fenders mount to the axle rather than the frame's eyelets. Always check that axle nuts are tight before riding.

Instruction Manual

Warning A Failure to install fenders properly may result in serious injury/death and or damage to your bicycle.



Installation

FRONT

- 1. Place fender through fork until fender tab aligns to brake mount hole (A). Do not mount
- 2. Install struts to fender with supplied hardware.
- Remove axle nuts and install struts using a washer on both sides if available. (See illustration B)
- 4. Install bolt through fender tab and into fork. Adjust clearance and struts and tighten.
- 5. Tighten axle nuts and double check all bolts are secure.
- 6. Spin wheel to check for tire rub or clearance issues.

REAR

- 1. Attach struts to fender body using supplied hardware.
- 2. Slip fender and struts onto rear wheel positioned so that the fender mounting tab is aligned with the chainstay bridge mounting hole. Bolt in place.
- Remove axle nuts and install struts using a washer on both sides if available. (See illustration B)
- 4. Tighten axle nuts and double check all bolt are secure.
- 5. Spin wheel to check for tire rub or clearance issues.

Note: Minor bending of struts outward may be necessary on some frames, this is normal and will not compromise structural integrity.